



General Power Supply for Laser Show



*Podesiti Res1 na Maximum pre ukljucenja napajanja
Zatim kada ukljucite napajanje, polako podesite (Res1) da max struja kroz LD bude oko 20mA
Nakon podesavanja struje kroz LD mozete ukloniti Ampermeter i na njegovo mesto kratkospojiti



Laser Diode Power Supply



Picture 1

Title		
Size Legal	Number mail_to: epraktikum@operamail.com	Revision v1.46
Date: 7-Oct-2001	Sheet of	
File: C:\DESIGN\PROJEKTI\LASER2\PROTE		Drawn By: ©Nebojsa Pejcic y2k